


# OWNER'S/ OPERATOR'S MANUAL

## MODEL NO. RBH-4000 and Telehandler Models

### CAUTION

For Safe Operation  
Read Rules And  
Instructions Carefully

SINO LEEINGLES, PIDA AYUDA  
A AIGUIEN QUE SI LO LEA  
PARA QUE LE TRADUZCA LAS  
MEDIDAS DE SEGURIDAD.



## RECTANGULAR BALE HANDLER for Tractor Front Loaders and some Telehandlers

Safety Instructions  
Tractor Preparation  
Operating Instructions

Assembly & Mounting  
Maintenance  
Repair Parts

### CAUTION

#### THE FOLLOWING SAFETY PRECAUTIONS SHOULD BE THOROUGHLY UNDERSTOOD BEFORE ATTEMPTING TO BEGIN ASSEMBLING THIS MACHINE

1. Select an area for assembly that is clean and free of any debris which might cause persons working on the assembly to trip.
2. Do not lift heavy parts or assemblies. Use crane, jack, tackle, fork trucks or other mechanical devices.
3. Preview the assembly instructions in your operator's manual before proceeding further.
4. If the assembly instructions call for parts or assemblies to be blocked up, use only blocking material that is in good condition and is capable of handling the weight of the assembly to be blocked. Also insure that the blocking material is on a clean, dry surface.
5. Never put hands, or any part of body, under blocked up assemblies if at all possible.
6. After completing assembly, thoroughly inspect the machine to be sure that all nuts, bolts, hydraulic fittings or any other fastened assemblies have been thoroughly tightened.
7. Before operating the machine, thoroughly read the operation section of your operator's manual.
8. Before operating, read the maintenance section of your operator's manual to be sure that any parts requiring lubrication, such as gearboxes, are full, to avoid any possible damage.
9. **Before operating equipment – If you have any questions regarding the proper assembly or operation, contact your dealer or representative.**

# TABLE OF CONTENTS

WARRANTY .....	2
SAFETY INFORMATION .....	3
SAFETY SIGNS .....	13
PREPARATION INSTRUCTIONS .....	14
OPERATING INSTRUCTIONS .....	16
OWNER MAINTENANCE & LUBRICATION .....	20
TROUBLE-SHOOTING .....	21
PARTS LISTS .....	23

SINO LEEINGLES, PIDA AYUDA A AIGUIEN QUE SI LO LEA PARA QUE LE TRADUZCA LAS MEDIDAS DE SEGURIDAD.

## STATEMENT OF POLICY

It is the policy of Worksaver, Inc. to improve its products where it is possible and practical to do so. Worksaver, Inc. reserves the right to make changes or improvements in design and construction at any time, without incurring the obligation to make these changes on previously manufactured units.

## TO THE OWNER:

Read this manual before using your Rectangular Bale Handler. This manual is provided to give you the necessary operating and maintenance instructions for keeping your Rectangular Bale Handler in top operating condition. Please read this manual thoroughly. Understand what each control is for and how to use it. Observe all safety signs on the machine and noted throughout the manual for safe operation of implement. Keep this manual handy for ready reference.

Like all mechanical products, it will require cleaning and upkeep. Lubricate the Rectangular Bale Handler as specified.

Use only genuine Worksaver, Inc. service parts. Substitute parts will void the warranty and may not meet standards required for safe and satisfactory operation. Record the model and serial number of your Rectangular Bale Handler here:

Model: \_\_\_\_\_ Serial Number: \_\_\_\_\_

---

---

## RETAIL CUSTOMER'S RESPONSIBILITY

It is the Retail Customer and/or Operator's responsibility to read the Operator's Manual, to operate, lubricate, maintain, and store the product in accordance with all instructions and safety procedures. Failure of the operator to read the Operator's Manual is a misuse of this equipment.

It is the Retail Customer and/or Operator's responsibility to inspect the product and to have any part(s) repaired or replaced when continued operation would cause damage or excessive wear to other parts or cause a safety hazard.

It is the Retail Customer's responsibility to deliver the product to the authorized Worksaver Dealer, from whom he purchased it, for service or replacement of defective parts which are covered by warranty. Repairs to be submitted for warranty consideration must be made within forty-five (45) days of failure.

It is the Retail Customer's responsibility for any cost incurred by the Dealer for traveling to or hauling of the product for the purpose of performing a warranty obligation or inspection.

# LIMITED WARRANTY

Worksaver warrants to the original purchaser of any new Rectangular Bale Handler (Model RBH-4000), that the equipment be free from defects in material and workmanship for a period of one (1) year for non-commercial, state, and municipalities. Use ninety (90) days for commercial use from date of retail sale.

Replacement or repair parts installed in the equipment covered by this warranty are warranted for sixty (60) days from the date of purchase of such part or to the expiration of the applicable new equipment warranty period, whichever occurs later.

Such parts shall be provided at no cost to the user during regular working hours. Worksaver reserves the right to inspect any equipment or parts which are claimed to have been defective in material or workmanship.

## DISCLAIMER OF IMPLIED WARRANTIES & CONSEQUENTIAL DAMAGES

Worksaver's obligation under this warranty, to the extent allowed by law, is in lieu of all warranties, implied or expressed, including implied warranties of merchantability and fitness for a particular purpose and any liability for incidental and consequential damages with respect to the sale or use of the items warranted. Such incidental and consequential damages shall include but not be limited to: transportation charges other than normal freight charges; cost of installation other than cost approved by Worksaver; duty; taxes; charges for normal service or adjustments; loss of crops or any other loss of income; rental of substitute equipment, expenses due to loss, damage, detention or delay in the delivery of equipment or parts resulting from acts beyond the control of Worksaver.

## THIS WARRANTY SHALL NOT APPLY:

1. To vendor items which carry their own warranties, such as hydraulic cylinders, tires, and tubes.
2. If the unit has been subjected to misapplication, abuse, misuse, negligence, fire or other accident.
3. If parts not made or supplied by Worksaver have been used in connection with the unit, if, in sole judgement of Worksaver such use affects its performance, stability, or reliability.
4. If the unit has been altered or repaired outside of an authorized Worksaver dealership in a manner which, in the sole judgement of Worksaver affects its performance, stability or reliability.
5. To normal maintenance service and normal replacement items such as gearbox lubricant, hydraulic fluid, worn blades, or to normal deterioration of such things as belts and exterior finish, due to use or exposure.
6. To expendable or wear items such as teeth, forged tines, plastic bearings, and other items that in the company's sole judgement is a wear item.

NO EMPLOYEE OR REPRESENTATIVE OF WORKSAVER IS AUTHORIZED TO CHANGE THIS WARRANTY IN ANY WAY OR GRANT ANY OTHER WARRANTY UNLESS SUCH CHANGE IS MADE IN WRITING AND SIGNED BY WORKSAVER'S SERVICE MANAGER, POST OFFICE BOX 100, LITCHFIELD, ILLINOIS 62056-0100.

# To the Owner/Operator/Dealer

All implements with moving parts are potentially hazardous. There is no substitute for a cautious, safe-minded operator who recognizes the potential hazards and follows reasonable safety practices. The manufacturer has designed this implement to be used with all its safety equipment properly attached to minimize the chance of accidents.

## BEFORE YOU START!!

Read the safety messages on the implement and shown in your manual.  
Observe the rules of safety and common sense!



**THIS SYMBOL MEANS**

- ATTENTION!
- BECOME ALERT!
- YOUR SAFETY IS INVOLVED!

THIS SAFETY ALERT SYMBOL IDENTIFIES IMPORTANT SAFETY WARNING MESSAGES. CAREFULLY READ EACH WARNING MESSAGE THAT FOLLOWS. FAILURE TO UNDERSTAND AND OBEY A SAFETY WARNING, OR RECOGNIZE A SAFETY HAZARD, COULD RESULT IN AN INJURY OR DEATH TO YOU OR OTHERS AROUND YOU. THE OPERATOR IS ULTIMATELY RESPONSIBLE FOR THE SAFETY OF HIMSELF, AS WELL AS OTHERS, IN THE OPERATING AREA OF THE POWER UNIT AND ATTACHED EQUIPMENT.

---

## UNDERSTAND SIGNAL WORDS

Note the use of the signal words **DANGER**, **WARNING** and **CAUTION** with the safety messages. The appropriate signal word for each has been selected using the following guidelines:

**DANGER:** Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. This signal word is to be limited to the most extreme situations typically for machine components which, for functional purposes, cannot be guarded.

**WARNING:** Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury, and includes hazards that are exposed when guards are removed. It may also be used to alert against unsafe practices.

**CAUTION:** Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

If you have questions not answered in this manual or require additional copies or the manual is damaged, please contact your dealer or the manufacturer directly.

---

## IMPORTANT SAFETY INFORMATION!

Working with unfamiliar equipment can lead to careless injuries. Read this manual, and the manual for your tractor or telehandler, before assembly or operating, to acquaint yourself with the machines. It is the implement owner's responsibility, if this machine is used by any person other than yourself, is loaned or rented, to make certain that the operator, prior to operating:

1. Reads and understands the operator's manuals.
2. Is instructed in safe and proper use.



The use of this equipment is subject to certain hazards which cannot be protected against by mechanical means or product design. All operators of this equipment must read and understand this entire manual, paying particular attention to safety and operating instructions, prior to using. If there is something in this manual you do not understand, ask your supervisor, or your dealer, to explain it to you.

# SAFETY INSTRUCTIONS (continued)



## EQUIPMENT SAFETY GUIDELINES



Safety of the operator is one of the main concerns in designing and developing a new piece of equipment. Designers and manufacturers build in as many safety features as possible. However, every year many accidents occur which could have been avoided by a few seconds of thought and a more careful approach to handling equipment. You, the operator, can avoid many accidents by observing the following precautions in this section. To avoid personal injury, study the following precautions and insist those working with you, or for you, follow them.



In order to provide a better view, certain photographs or illustrations in this manual may show an assembly with a safety shield removed. However, equipment should never be operated in this condition. Keep all shields in place. If shield removal becomes necessary for repairs, replace the shield prior to use.



Replace any CAUTION, WARNING, DANGER or instruction safety sign that is not readable or is missing. Location of such safety signs is indicated in this booklet.



Never use alcoholic beverages or drugs which can hinder alertness or coordination while operating this equipment. Consult your doctor about operating this machine while taking prescription medications.



Review the safety instructions with all users annually.



This equipment is dangerous to children and persons unfamiliar with its operation. The operator should be a responsible adult familiar with farm machinery and trained in this equipment's operations. **Do not allow persons to operate or assemble this unit until they have read this manual and have developed a thorough understanding of the safety precautions and of how it works.**



To prevent injury or death, power unit must be equipped with ROPS or ROPS cab and seat belt. Keep seat belt securely fastened. Falling off power unit can result in death from being run over or crushed. Keep foldable ROPS system in "locked up" position at all times.



Never exceed the limits of a piece of machinery. If its ability to do a job, or to do so safely, is in question - **DON'T TRY IT.**



Do not modify the equipment in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the equipment.



In addition to the design and configuration of this implement, including Safety Signs and Safety Equipment, hazard control and accident prevention are dependent upon the awareness, concern, prudence, and proper training of personnel involved in the operation, transport, maintenance, and storage of the machine. Refer also to Safety Messages and Operation Instructions in each of the appropriate sections of the Tractor, Telehandler, and Implement Manuals. Pay close attention to the Safety Signs affixed to the Tractor, Telehandler, and the Implement.

# **SAFETY INSTRUCTIONS (continued)**



## **SAFETY TRAINING**

-  Safety is a primary concern in the design and manufacture of our products. Unfortunately, our efforts to provide safe equipment can be wiped out by a single careless act of an operator.
-  In addition to the design and configuration of equipment, hazard control and accident prevention are dependent upon the awareness, concern, prudence and proper training of personnel involved in the operation, transport, maintenance and storage of equipment.
-  It has been said, “The best safety device is an informed, careful operator.” We ask you to be that kind of an operator. It is the operator’s responsibility to read and understand ALL Safety and Operating instructions in the manual and to follow these. Accidents can be avoided.
-  Working with unfamiliar equipment can lead to careless injuries. Read this manual, and the manual for your tractor, before assembly or operating, to acquaint yourself with the machines. It is the equipment owner’s responsibility, if this machine is used by any person other than yourself, is loaned or rented, to make certain that the operator, prior to operating:
1. Reads and understands the operator’s manuals.
  2. Is instructed in safe and proper use.
-  Know your controls and how to stop tractor, engine, and loader quickly in an emergency. Read this manual and the one provided with your tractor.
-  Train all new personnel and review instructions frequently with existing workers. A person who has not read and understood all operating and safety instructions is not qualified to operate the machine. An untrained operator exposes himself and bystanders to possible serious injury or death.
-  Do not allow children to operate this machine.

# SAFETY INSTRUCTIONS (continued)



## SAFETY SIGNS

-  Keep safety signs clean and legible at all times.
-  Replace safety signs that are missing or have become illegible.
-  Replaced parts that displayed a safety sign should also display the current sign.
-  Safety signs are available from your Distributor or Dealer Parts Department or the factory.

### **How to Install Safety Signs:**

-  Be sure that the installation area is clean and dry.
-  Be sure temperature is above 50°F (10°C).
-  Decide on the exact position before you remove the backing paper.
-  Remove the smallest portion of the split backing paper.
-  Align the sign over the specified area and carefully press the small portion with the exposed sticky backing in place.
-  Slowly peel back the remaining paper and carefully smooth the remaining portion of the sign in place.
-  Small air pockets can be pierced with a pin and smoothed out using the piece of sign backing paper.



## STARTING AND STOPPING SAFETY

-  Be certain the power unit is in neutral or park position before starting engine.
-  Always shut off power unit and shift to “Park” or set brakes when leaving power unit. Always lower bucket or attachment to ground, relieve all hydraulic pressure. Remove key when leaving power unit unattended. Park in level area.
-  Before operating equipment: if you have any questions regarding the proper assembly or operation, contact your dealer or representative.

# SAFETY INSTRUCTIONS (continued)



## OPERATIONAL SAFETY

-  The use of this equipment is subject to certain hazards which cannot be protected against by mechanical means or product design. All operators of this equipment must read and understand this entire manual, paying particular attention to safety and operating instructions, prior to using. If there is something in this manual you do not understand, ask your supervisor, or your dealer, to explain it to you.
-  Most accidents occur because of neglect or carelessness. Keep all helpers and bystanders fifty feet (50') from an operating power unit and attached equipment. Only properly trained people should operate this machine. It is recommended the power unit be equipped with a Rollover Protection System (ROPS) and a seat belt that is used. Always stop the power unit, set brake, shut off the engine, remove the key, and lower loader to the ground before dismounting tractor. Never leave equipment unattended with the power unit running.
-  Please remember it is important that you read and heed the safety signs on the front loader attachment and loader, and the safety rules set forth. Clean or replace all safety signs if they cannot be clearly read and understood. They are there for your safety as well as the safety of others. The safe use of this machine is strictly up to you, the operator.
-  Be sure power unit is in good condition. Read all the safety precautions and make sure all operators are familiar with the safety rules of operation.
-  Know your controls and how to stop power unit and engine quickly in an emergency. **READ THIS MANUAL AND THE ONE PROVIDED WITH YOUR TRACTOR AND LOADER OR TELEHANDLER.**
-  When the use of hand tools is required to perform any part of assembly, installation, adjustment, maintaining, repairing, removal, or moving the implement, be sure the tools used are designed and recommended by the tool manufacturer for that specific task.
-  Personal protection equipment including safety glasses, safety shoes, and gloves are recommended during assembly, installation, operation, adjustment, maintaining, repairing, removal, or moving the attachment.
-  Always use two people to handle heavy, unwieldy components during assembly, installation, removal, or moving the loader attachment.
-  Never place any part of your body where it would be in danger if movement should occur during assembly, installation, operation, maintaining, repairing, removal, or moving the implement.
-  The use of any loader attachment is **NOT** recommended on tractor with a tricycle wheel arrangement. Tricycle type tractors are unstable for front loader use.
-  A heavy load can cause instability in driving a tractor. Make sure the front or rear of the tractor is properly counter-balanced with weights. Always drive slowly – especially around turns. An unstable tractor could steer badly and possibly tip over, causing injury or death.
-  Do not allow others to ride on the power unit with an operator. Riders are subject to injury such as being struck by foreign objects or being thrown off. Riders obstruct the operator's view resulting in unsafe operation. **Never allow anyone to ride on the implement!**

# **SAFETY INSTRUCTIONS (continued)**



## **OPERATIONAL SAFETY (continued)**



Before you operate any equipment, check over all pins, bolts and connections to be sure all are securely in place. Replace any damaged or worn parts immediately.



Do not work under a raised loader unless it is securely blocked or held in position. Do not depend on the power unit hydraulic system to hold the implement in place.



Operate the loader controls smoothly, avoiding jerky operation. Stop loader gradually when lowering or lifting loads.



Beware of low electrical wires when loader is raised. Serious injury or death can result if contact is made.



When handling bales on a slope, always approach the bale with the power unit facing uphill.



Never use the tractor/loader or telehandler to stop a rolling bale.



Only use a power unit equipped with a ROPS cab or rollover protective structure.



When stacking bales, ALWAYS MAKE SURE BALES ARE PLACED SO THE STACK IS STABLE.



Keep all bystanders at a safe distance. REMEMBER FALLING BALES CAN ROLL OR TUMBLE.



Do not handle bales that exceed the weight limitations of the loader.



Carry the bales slowly and as low as practical to the ground.



For operator safety, always keep load in front of power unit hood. NEVER position load back over operator. ALWAYS BE CAREFUL!



Always load rear of tractor first and unload last when using a front loader.



Beware of lift clearance when raising loader to maximum height.



Keep alert and watch the rear as well as the front when working with the loader.

# SAFETY INSTRUCTIONS (continued)



## OPERATIONAL SAFETY (continued)

-  When maneuvering close to buildings or passing through narrow areas, be sure to allow sufficient clearance for the power unit, loader, and bales. Drive slowly.
-  Operate power unit from operator's seat only. Remain at controls until operating cycle is complete.
-  Use extreme care when working on inclines and hillsides.
-  Avoid steep slopes or unstable surfaces. When operating on a slope keep the load low and proceed with extreme caution. **DO NOT** drive **ACROSS** a steep slope, drive straight up and down. With a loaded attachment – face the attachment and load uphill. With an empty attachment – face the attachment downhill.
-  Do not lower the boom if it is raised and retracted and the attachment is rotated in the downward position. Spikes or tines on the attachment may contact and damage the front wheels of the operating machine.
-  Never stack loads on uneven ground. Loads stacked on uneven ground can topple.
-  Electrocution can result from contacting or approaching underground or overhead power cables. Check overhead clearances; know your margin of safety. If possible, have power lines disconnected, if not possible, request a signal person for guidance.
-  Do not lift or carry anyone on loader or in bucket or on attachment. Do not use loader for a work platform.
-  **ALWAYS** lower loader to the ground or block securely before performing any maintenance work.
-  Never allow anyone to walk or work under a raised loader.
-  Be sure that people, livestock, or pets are not standing near the machine while operating.
-  Do not operate close to ditches, creeks or holes. Slow down when operating over rough ground.
-  Avoid excessive speed during operation. Use extreme care when working on inclines and hillsides.
-  Always keep power unit on solid footing when operating loader.
-  Observe Safety Recommendations in loader instruction manual.
-  Inspect the entire machine periodically as indicated in the Maintenance Section of this manual. Look for loose fasteners, worn or broken parts, pinched hydraulic hoses, and leaky or loose fittings. Make sure all pins have cotter pins and washers. Serious injury may occur from not maintaining this machine in good working order.

# SAFETY INSTRUCTIONS (continued)



## TRANSPORT SAFETY

-  Comply with state and local laws governing highway safety and movement of farm machinery on public roads.
-  The use of flashing amber lights is acceptable in most localities. However, some localities prohibit their use. Local laws should be checked for all highway lighting and marking requirements.
-  When driving equipment on the road or highway under 20 mph (32 kph) at night or during the day, use flashing amber warning lights and a slow moving vehicle (SMV) identification emblem.
-  Always be sure the implement is in the proper position for transport.
-  Reduce speed when transporting mounted implements to avoid bouncing and momentary loss of steering control.
-  Plan your route to avoid heavy traffic.
-  Do not travel on the road with bales on the Bale Handler. The power unit may tip if the brakes are applied quickly or if a rapid turn is made.
-  Do not drink and drive!
-  Watch for traffic when operating near or crossing roadways.
-  Turn curves or go up or down hills only at a low speed and at a gradual steering angle. Make certain that at least 20% of the tractor's weight is on the front wheels to maintain safe steering. Slow down on rough or uneven surfaces, and loose gravel.
-  Use extreme care and maintain minimum ground speed when transporting on hillside, over rough ground and when operating close to ditches or fences. Be careful when turning sharp corners.
-  Never allow riders on either power unit or implement. Falling off can kill.
-  Be a safe and courteous driver. Always yield to oncoming traffic in all situations, including narrow bridges, intersections, etc.
-  Do not exceed 20 mph (32 kph). Reduce speed on rough roads and surfaces.

# SAFETY INSTRUCTIONS (continued)



## MAINTENANCE SAFETY

-  Good maintenance is your responsibility. Poor maintenance is an invitation to trouble.
  
-  Follow good shop practices.
  - Keep service area clean and dry.
  - Be sure electrical outlets and tools are properly grounded.
  - Use adequate light for the job at hand.
  
-  Make sure there is plenty of ventilation. Never operate the engine of the vehicle in a closed building. The exhaust fumes may cause asphyxiation.
  
-  Before working on this machine, drive to a level area, disengage the PTO, lower implement or loader (or if working underneath, raise and block securely), shut off the engine, relieve all hydraulic pressure, set the brakes, and remove the ignition keys.
  
-  Be certain all moving parts on attachments have come to a complete stop before attempting to perform maintenance.
  
-  Never work under equipment unless it is blocked securely. Never depend on hydraulic system to keep implement in raised position.
  
-  Keep all persons away from operator control area while performing adjustments, service, or maintenance.
  
-  Always use personal protection devices such as eye, hand and hearing protectors, when performing any service or maintenance.
  
-  Periodically tighten all bolts, nuts and screws and check that all cotter pins are properly installed to ensure unit is in a safe condition.
  
-  When completing a maintenance or service function, make sure all safety shields and devices are installed before placing unit in service.
  
-  Openings in the skin and minor cuts are susceptible to infection from hydraulic fluid. If injured by escaping hydraulic fluid, see a doctor at once. Gangrene and death can result. Without immediate medical treatment, serious infection and reactions can occur.

# SAFETY INSTRUCTIONS (continued)



## MAINTENANCE SAFETY (continued)



After servicing, be sure all tools, parts and service equipment are removed.



Check to ensure all safety signs are installed and in good condition. (See safety sign section for location drawing.)



Do not allow grease or oil to build up on any deck or platform.



Never replace hex bolts with less than grade five bolts unless otherwise specified, i.e. shear bolts. Refer to bolt torque chart for head identification marking.



Where replacement parts are necessary for periodic maintenance and servicing, genuine factory replacement parts must be used to restore your equipment to original specifications. The manufacturer will not claim responsibility for use of unapproved parts and/or accessories and other damages as a result of their use.



If equipment has been altered in any way from original design, the manufacturer does not accept any liability for injury or warranty.



A fire extinguisher and first aid kit should be kept readily accessible while performing maintenance on this equipment.



## STORAGE SAFETY



Following operation or when unhooking, stop the power unit, set the brakes, shut off the engine, relieve all hydraulic pressure and remove the ignition keys.



Store the unit in an area away from human activity.



Do not park equipment where it will be exposed to livestock for long periods of time. Damage and livestock injury could result.



Do not permit children to play on or around the stored unit.




Make sure all parked machines are on a hard, level surface and engage all safety devices.



If blocking is used, make sure it is solid and secure before leaving area.

# SAFETY SIGNS

 <b>WARNING</b>	
	
<b>HIGH-PRESSURE FLUID HAZARD</b>	
To prevent serious injury or death:	
<ul style="list-style-type: none"><li>• Relieve pressure on system before repairing or adjusting or disconnecting.</li><li>• Wear proper hand and eye protection when searching for leaks. Use wood or cardboard instead of hands.</li><li>• Keep all components in good repair.</li></ul>	
SW700	

 <b>WARNING</b>
<ul style="list-style-type: none"><li>• Read and follow owner's manual before installing, operating, or performing maintenance on this loader. Observe safety recommendations in manual.</li><li>• Do not exceed weight limit of loader or tractor.</li><li>• Do not lift or carry anyone on loader or in bucket or attachment.</li><li>• For operator safety, always keep load in front of tractor hood. NEVER position load back over operator.</li><li>• Add recommended wheel ballast or rear weight for stability. When handling loads on both ends of tractor, load rear first and unload last.</li><li>• Set wheels wide for increased stability.</li><li>• Never raise loader to extreme heights on steep inclines.</li><li>• Do not stand or work under raised loader.</li><li>• Stop engine, lower arms, relieve all hydraulic pressure, and lock brakes before leaving operator's seat.</li><li>• When handling round bales with fork type equipment, be sure bolt-in stabilizer spike is installed. Without spike, uncontrolled bale movement could occur.</li><li>• Failure to observe the above precautions can result in serious injury or death.</li></ul>
101026

 <b>WARNING</b>
<b>Stand clear</b>
101027

REMEMBER: If Safety Signs have been damaged, removed, become illegible or parts replaced without Signs, new Safety Signs must be applied. New Safety Signs are available from your authorized distributor or factory.

# INSTRUCTIONS

---

## TRACTOR AND TELEHANDLER REQUIREMENTS AND PREPARATION

---

The Rectangular Bale Handler is designed to handle and stack large size rectangular bales. It can handle two 4' x 4' x 8' bales or three 3' x 3' x 8' bales.

Two 2 1/2" bore x 8" stroke hydraulic cylinders operate the curved hook bars to grip and hold the bales. Five 26" long forged tines support the bales at the bottom. An additional six 18" forged spears supply additional support.

The Rectangular Bale Handler is available with a model for front tractor loaders and models for some makes and models of Telehandlers.

The Model RBH-4000 is recommended for farm tractors with a PTO horsepower rating of at least 85 hp and equipped with a front loader rated at 4,000 lb or more. Optional brackets are available to fit most popular quick coupler front-end loaders.

One pair of remote hydraulic coupler outlets are required to operate the bale handler cylinders (This is in addition to the hydraulic circuits required for the loader).

Telehandler units need to have sufficient lift capacity to handle the expected load and the weight of the Bale Handler.

**NOTE:** The Bale Handler is only recommended for tractors and Telehandler units equipped with a rollover protective structure (ROPS) cab.

**NOTE:** Worksaver does **NOT** recommend the use of any loader attachment on tractors with a tricycle wheel arrangement.

Check the power unit's hydraulic system. Be sure the hydraulic oil and filter have been serviced according to manufacturer's recommendations. Refer to your tractor or loader operator's manual or dealer for any adjustments necessary to put the hydraulic system in good working order.

Be sure tires and rims are in good condition. Inflate tires to the proper recommended air pressure.

Power unit must be equipped with ROPS or ROPS CAB and seat belt. Keep seat belt securely fastened. Falling off power unit can result in death from being run over or crushed. Keep foldable ROPS system in "locked up" position at all times.



Be sure your tractor and loader, or telehandler is in good condition. Read all the safety precautions and make sure all equipment operators are familiar with the safety rules of operation.

The operator is responsible for the safe operation of this equipment. The operator must be properly trained. Operators should be familiar with the telehandler, tractor, loader and loader attachment, and all safety practices before starting operation. Read the safety rules and safety signs on pages 3-13.



A heavy load can cause instability in driving a power unit. Make sure the rear of the tractor is properly counterbalanced with weights. Always drive slowly – especially around turns. An unstable power unit could steer badly and possibly tip over, causing injury or death.

## ASSEMBLY

---

This unit is shipped almost completely assembled.

Refer to the "exploded views" on pages 23-25 of this manual.

Carefully follow instructions for final assembly.

Before attempting assembly check the following items. Having all the needed parts and equipment readily at hand will speed up your assembly task and will make the job as safe as possible.

- Check for fasteners and pins that were shipped with the Rectangular Bale Handler.
- Have a fork lift or loader along with chains and safety stands that are sized for the job ready for the assembly task.
- Have a minimum of 2 people at hand during assembly.
- Check to see that all nuts are tightened.

Remove the bucket from your front end loader or telehandler. Check your loader to make sure it is in good working order. Check all frame mounting bolts to make sure they are tight.

Loaders that attach to the tractor frame rails should have a cross-tie installed for stability.

# INSTRUCTIONS (continued)

## ASSEMBLY – TRACTOR LOADERS

Remove the bucket from your front end loader. Check your loader to make sure it is in good working order. Check all frame mounting bolts to make sure they are tight.

Assemble the two lift brackets (Ref. #18) on the main frame (Ref. #1) with the  $\frac{5}{8}$ " x 3" I.D. U-bolts. Leave the U-bolts loose.

**NOTE:** The lift channel brackets are supplied with 1" diameter pins to fit your loader. If your loader requires  $1\frac{1}{8}$ " pins, it will be necessary for the hole diameter in the channel brackets to be drilled out to  $1\frac{5}{32}$ " (1.156") and ask your dealer to order  $1\frac{1}{8}$ " diameter pins. The  $1\frac{1}{8}$ " pins are part #830318. Be sure to indicate if two or four  $1\frac{1}{8}$ " pins are required.

If your loader requires  $1\frac{1}{4}$ " diameter pins, please ask your dealer to order adapter bushings (part #830319). Be sure to indicate how many adapter bushings are required.

**NOTE:** The Ford Model 7109, 7209, 7210 and 7410 Pin Type Loaders require special mounting brackets instead of the standard lift channels supplied. Order #830330 for this application.

**NOTE:** Loaders with only one hydraulic cylinder in the center of the loader to tilt the bucket or attachment may NOT be used with the Rectangular Bale Handler.

If your tractor loader has a bucket Quick Attach feature, check with your dealer on the availability of adapter brackets for your brand and model loader.

Connect the above assembly to the loader arms using the bottom hole in the channel and attach the upper control cylinder to the top hole in the lift channels. Center the main frame (side to side) with your loader arms and tighten the four (4)  $\frac{5}{8}$ " x 3" U-Bolts.

The lower hole positions in the lift channels can be used to obtain more angle movement. However, if the frame becomes too parallel with the loader lift arms, the loader may not have enough power (mechanical advantage) to bring the frame back.

**NOTE:** Generally, it is not recommended to have the tilt cylinders located any closer than 10-12 inches to the main loader lift arms. Check the spacing of mounting pins on your loader bucket and use this as a guide.

If tilt cylinders are located too close to the loader arms, they may go "over center" when fully extended. If this happens, damage may occur to the cylinders and/or mounting brackets.

## TELEHANDLER MOUNTING

Remove the bucket from your telehandler unit and connect the main frame of the Bale Handler to the quick-attach coupler.



**To help prevent personal injury, stand clear of frame and loader. Keep feet away from underside of main frame.**

The Bale Handler Telehandler models have a quick-attach bracket welded on the frame. No other special brackets are required. Make sure latch pins engage to lock the frame in place.

## ASSEMBLY – TELEHANDLER AND TRACTOR LOADERS

Route the hoses (not supplied) back to your tractor/loader remote hydraulic couplers. Be sure to allow a loop of hose just behind the attachment to allow for the tilt angles that will be encountered. Make sure that the hoses are routed so they will not be pinched or snagged by attachment pivot arms, loader, or tractor parts. Fasten the hoses securely so they will remain in the correct position and not drop down where they could be pinched or sheared.

Use a good thread sealant. (**DO NOT USE TEFLON TAPE** as this could cause hydraulic system problems in your tractor or power unit.)

After making the hose connection between the tractor/telehandler remote outlets and the hydraulic cylinders, operate the bale handler hooks several times to work the air out of the system.



**Escaping hydraulic fluid under pressure can penetrate the skin, causing serious injury.**

**DO NOT use your hand to check for leaks. Use a piece of cardboard or paper to search for leaks.**

**Stop engine and relieve pressure before connecting or disconnecting lines.**

**Tighten all connections before starting engine or pressurizing lines.**

**If any fluid is injected into the skin, obtain medical attention immediately, or gangrene may result.**

# OPERATING INSTRUCTIONS


## PRE-OPERATION CHECKLIST

(OWNER/OPERATOR RESPONSIBILITY)

- \_\_\_ Review and follow safety rules and safety signs on pages 3 through 13.
- \_\_\_ Check that Bale Handler is properly and securely attached to tractor loader or telehandler.
- \_\_\_ Lubricate all grease fitting locations.
- \_\_\_ Check that all hardware is properly installed.
- \_\_\_ Check that no one enters the area of machine operation. Always work at a safe distance from roads, built-up areas, or populated places.
- \_\_\_ Know your controls and how to stop power unit, engine and PTO quickly in an emergency. **READ THIS MANUAL AND THE ONE PROVIDED WITH YOUR POWER UNIT.**
- \_\_\_ To avoid accident or injury, do not allow anyone to operate this equipment without proper instructions. Any person who operates this equipment must be instructed in and be capable of the safe operation of the tractor, telehandler, attachment and all controls.

## OPERATION

Be sure tractor is properly counter-balanced with weights before attempting to lift any load with the Bale Handler Attachment.



When working on side hills, **DO NOT RAISE LOADER TOO HIGH.** Keep an eye on terrain changes. Keep load low.

## SAFETY INSTRUCTIONS

Observe all instruction and safety decals on the Bale Handler. These safety signs are shown for reference. Read them carefully before using the Bale Handler. Replace any decals that may be faded or damaged.

Make sure all operators have read the Owner's/Operator's Manual and are familiar with the instructions and the safety rules of operation.

### **OPERATE LOADER SAFELY**

- Improper use of loader can cause serious injury or death.
- Become familiar with controls.
- Be sure anyone operating the loader is aware of safe operation and potential hazards. Read and observe safety recommendations in loader manual.
- Operate loader from operator's seat only. Remain at controls until operating cycle is complete.
- Stop loader gradually when lowering or lifting loads.
- Use particular care when working on inclines and hillsides.
- Avoid holes, ditches, and obstructions which may cause tractor/loader to tip.
- Allow for additional length of loader on tractor while turning.
- Never allow anyone to walk or work under a raised loader.
- Be sure that people, livestock, or pets are not standing near the machine while operating.
- Do not handle loads that exceed the weight limitations of the loader.
- Carry the loads slowly and as low as possible to the ground.
- Operate the loader hydraulic controls smoothly, avoiding jerky operation.
- When handling material on a slope, always approach the material with the power unit facing uphill.
- Only use a tractor or power unit equipped with a ROPS cab or roll-over protective structure.
- Travel slowly over rough ground or when making turns.
- Lower bucket or attachment to ground when loader is unattended.

# OPERATING INSTRUCTIONS (continued)

## OPERATION (continued)

Only qualified people familiar with this manual should operate this machine. Operator should wear hard hat, safety glasses, and safety shoes. It is required that the power unit be equipped with Roll-Over Protective System (ROPS) and a seat belt be used. (A four post ROPS or a ROPS equipped with a heavy duty sun shade works best.) Check for ditches, stumps, holes, or other obstacles that could upset power unit or damage the bale handler. Always turn off engine, set parking brake, lower loader to ground and relieve hydraulic pressure before dismounting power unit.

Safety is a primary concern in the design and manufacture of our products. Unfortunately, our efforts to provide safe equipment can be wiped out by a single careless act of an operator.

It has been said, "The best safety device is an informed, careful operator". We ask you to be that kind of an operator.

The designed and tested safety of this machine depends on it being operated within the limitations as explained in this manual. Be familiar with and follow all safety rules in the manual, on the bale handler and on the tractor or telehandler.

The safe operation of this machine is the responsibility of the owner/operator. The operator should be familiar with the bale handler and power unit and all safety practices before starting operation. Read the safety rules on pages 3-13.

Before using the Bale Handler, check all bolts, hydraulic hoses, and fittings to be sure they are properly installed.

After the Bale Handler has been installed on the loader, raise it up and down and tilt it up and down, check for any binding that may occur between the loader and loader brackets. If any binding is occurring, it must be remedied before damage occurs.



**Damage to equipment, or personal injury could occur if Bale Handler is not properly attached to the loader. The Bale Handler could become detached from the loader and fall.**

## HANDLING BALES

Operation of the Bale Handler is relatively simple, however, experience is very important in making a tight, straight stack. The Bale Handler, along with the operator skill, will allow you to move bales without manual labor.

## INDIVIDUAL BALES

If the bales are individually scattered in the field, the bales will have to be picked up one at a time. Approach the first bale with the Bale Handler in a horizontal position and with the hooks retracted. Lower the horizontal Bale Handler until the frame is 10"-12" above the top of the bale. Gently nudge the long side of the bale with the five forged tines at the bottom of the Bale Handler to align the bale with the handler. Then lower the frame on top of the bale and apply only a slight down pressure. **DO NOT FORCE** the frame down so hard that weight is transferred from the tractor to the frame. Now engage the hooks by operating the proper hydraulic control lever on the power unit.

Raise the Bale Handler 16"-24" above the ground and drive to the second bale. When close to the second bale, lower the Bale Handler until the frame is 10"-12" above the top of the second bale. Gently nudge the long side of the second bale to align it with the first bale and the Bale Handler. Now disengage the hooks from the first bale, allowing it to drop to the ground. Then lower the Bale Handler frame as done for the first bale. Then engage the hooks in both bales and raise the Bale Handler.

If handling "Mid-size" rectangular bales, repeat the above process for the third bale. If handling "large" (4' x 4' x 8') bales, two bales will be a full load.

Raise the Bale Handler 16"-24" and drive to the truck to be loaded or location of the stack.

## GROUPED BALES

If the bales have been grouped together with the use of a bale accumulator or other baler attachment the Bale Handler can accommodate two "large" 4' x 4' x 8' bales or three 30" x 30" x 8' "Mid-sized" bales.

Approach the bales with the Bale Handler in a horizontal position and with the hooks retracted. Lower the Bale Handler until the frame is 10"-12" above the top of the bales. Gently nudge the long side of the bales with the five tines at the bottom of the Bale Handler to align the bales with the handler. Then lower the frame on top of the bales and apply only a slight down pressure. **DO NOT FORCE** the frame down so hard that weight is transferred from the tractor to the frame.

Engage the hooks by operating the proper hydraulic control lever on the power unit.

Raise the Bale Handler 16"-24" above the ground and drive to the tract to be loaded or location of the stack.

# OPERATING INSTRUCTIONS (continued)

## **! WARNING! !**

Never allow anyone to ride on the Bale Handler or to stand or walk under it. The Bale Handler or bales could drop unexpectedly.

Always keep the Bale Handler as low as possible, and travel at a speed safe for conditions present, to prevent overturning the tractor or telehandler.

## **PLACING BALES**

To place the bales in a stack or on a trailer, move the Bale Handler to the desired location and disengage the hooks by using the proper hydraulic control lever.

Bales may be stacked tight together by approaching the stack at a slight angle, then turning into already stacked bales to force the bales together. Use only minor force when doing this because excessive side-force may cause damage to the loader or Bale Handler.

There are several satisfactory methods for stacking bales with the Bale Handler. If a barn or shed is used, the stack may be built straight up. If the stack is outside, in high wind or rain areas, some taper may want to be used. Location and operator skill will determine the success of any method used. Stack height depends on the lifting height of the loader, and the density of the bales. Soft bales cannot be stacked as high as denser bales. A high-density bale is important for a solid stack; however, softer bales may be used if the stack is built with more taper.

Extra hooks may be added to the Bale Handler if there is difficulty in gripping the bales.

DO NOT USE the Bale Handler for any other purpose than moving bales.

## **! CAUTION! !**

Beware of lift clearance when raising loader to maximum height.

When stacking or loading vehicles, make sure you are operating in an area AWAY FROM OVERHEAD WIRES.

## **! DANGER! !**

Beware of low electrical wires when loader is raised. Serious injury or death can result if contact is made.

## **OPERATING PRECAUTIONS**

Do not force the Bale Handler down on the bales. The weight of the Bale Handler and loader is sufficient.

Never lower the front of the Bale Handler first.


Verify that the Bale Handler frame is flat on the bales before engaging hooks.

Never raise the front of the tractor or power unit by forcing the Bale Handler down. This causes extreme stress on the frame and brackets.

Keep the Bale Handler as low as practical at all times to reduce the possibility of tipping or contacting overhead wires or obstructions.

Braking efficiency will also be less if the center of gravity is raised.

Do not push or pull with the Bale Handler. Structural damage may result. Also, this may cause power unit to tip.




Do not force the Bale Handler down on the bales. The weight of the Bale Handler and loader is sufficient. Never lower the front of the Bale Handler first. Verify that the Bale Handler is flat on the bales before engaging the hooks. Never raise the front of the power unit by forcing the Bale Handler down. This causes extreme stress on the Bale Handler and brackets.

# OPERATING INSTRUCTIONS (continued)


## OPERATING PRECAUTIONS (cont.)



Keep the Bale Handler as low as practical at all time to reduce the possibility of tipping or contacting overhead obstructions. Braking efficiency will also be less if the center of gravity is raised.



Do not push or pull with the Bale Handler. Structural damage may result. Also this may cause the tractor to tip.



When transporting the bales, keep the Bale Handler low. Always travel at a safe and responsible speed. The increased weight on the front axle, and possible increased height, reduces the stability of the power unit and its braking efficiency.

## TRANSPORTING



When traveling on public roads, whether at night or during the day, use accessory light and devices for adequate warnings to operators of other vehicles. Comply with all federal, state and local laws.

Do not travel on the road with bales on the Bale Handler. The power unit may tip if the brakes are applied quickly or if a rapid turn is made.

Check visibility. If visibility is impaired, reduce speed or consider other means of bale transport.

Allow for additional length of loader and attachment on power unit while turning.

Select a safe ground travel speed when transporting from one area to another. When traveling on roadways, transport in such a way that faster moving vehicles may pass you safely.

When traveling over rough or hilly terrain or when making turns, slow down and use extra care.

Read all the safety warnings in the front of this manual and in the manual of tractor or telehandler unit.

## STORAGE

- At the end of the working season or when the Bale Handler will not be used for a long period, it is good practice to clean off any dirt or grease that may have accumulated.
- Inspect the Bale Handler for loose, damaged or worn parts and adjust or replace if needed.
- Sand areas where paint is chipped or worn and repaint to prevent rust.
- Always store in a safe place away from children or livestock.
- Storage location should be level and solid to make hitching and unhitching easy.
- Block equipment securely for storage.

# OWNER SERVICE

## MAINTENANCE

The information in this section is written for operators who possess basic mechanical skills. Should you need help, your dealer has trained service technicians available. For your protection, read and follow all safety information in this manual.

### **WARNING!**

■ **NEVER GO UNDERNEATH EQUIPMENT.** Never place any part of the body underneath equipment or between moveable parts even when the engine has been turned off. Hydraulic system leak down, hydraulic system failures, mechanical failures, or movement of control levers can cause equipment to drop or rotate unexpectedly and cause severe injury or death.

- Service work does not require going underneath.
- Read Manual for service instructions or have service performed by a qualified dealer.

### **WARNING!**

■ Keep all persons away from operator control area while performing adjustments, service, or maintenance.

■ Before dismounting power unit or performing any service or maintenance, follow these steps: disengage power to equipment, lower the 3 point hitch and all raised components to the ground, operate valve levers to release any hydraulic pressure, set parking brake, stop engine, remove key, and unfasten seat belt.

### **CAUTION!**

■ Always wear relatively tight and belted clothing to avoid entanglement in moving parts. Wear sturdy, rough-soled work shoes and protective equipment for eyes, hair, hands, hearing, and head.

If the machine is used in heavy duty conditions, the maintenance operations must be carried out more frequently.

Thoroughly clean the grease zerks before servicing. Dirt mixed with lubricant will rapidly wear parts and destroy bearings. Keep it clean.

Check the pins at the ends of the loader arms. Make sure they are locked in place with the linchpins.

Periodically check all bolts to make sure they are tight.

Check hydraulic hoses. Make sure they are not chafed or pinched. Replace any damaged hose.

Check hydraulic hoses and fittings for leaks. Repair any leaks immediately. Never use your hand to check for a hydraulic leak when system is under pressure.

Replace any worn or damaged parts immediately. Do not use attachment with any damaged parts.

**REPLACE SAFETY SIGNS  
IF DAMAGED OR MISSING.**

**OBEY ALL  
SAFETY WARNINGS!**

# TROUBLE-SHOOTING GUIDE


---

PROBLEM	POSSIBLE CAUSE	POSSIBLE REMEDY
<p><b>Bale Handler hooks will not operate.</b></p>	<p>1. No or insufficient oil flow.</p>	<p>Remote hydraulic connection fittings not compatible. Check for proper fitting.</p> <p>Hydraulic system may not be supplying rated pressure. Consult your dealer.</p> <p>Hydraulic system may not be delivering its rated volume of oil due to wear. Hydraulic pump may need to be repaired.</p> <p>Hydraulic valve on tractor or telehandler not engaged.</p>
<p><b>Bale Handler is loose on loader.</b></p>	<p>1. Attachment not correct.</p>	<p>U-bolts that connect quick-attach brackets to main frame may be loose or worn. Tighten or replace U-bolts</p> <p><b>NOTE:</b> If bolts are loose or damaged, it could be that they were never properly tightened. It also could be that the operator is impacting the Bale Handler into bales or ground during operation.</p> <p>Bale Handler mount may not be properly latched on tractor or telehandler loader. Check lock pins.</p>
<p><b>Bent or broken hooks.</b></p>	<p>1. Improper operation.</p> <p>2. Hitting foreign objects in bale.</p> <p>3. Extremely hard, tight bales.</p> <p>4. Loose hooks.</p>	<p>Operator dropping frame down on bales without first retracting hooks – retrain operator.</p> <p>Check bales for tree limbs or other foreign objects.</p> <p>Bales are made with “green” material for silage bales – the Bale Handler may not be the proper attachment for this situation.</p> <p>Check U-bolts connecting book to square shaft – tighten nuts.</p>
<p><b>Hydraulic hose failure.</b></p>	<p>1. Hydraulic relief pressure setting is very high and may cause hydraulic hose failure.</p> <p>2. Hoses are worn or frayed.</p> <p>3. Hose rating may be too low for hydraulic system pressure.</p>	<p>Check hydraulic system and adjust relief valve.</p> <p>Replace hose.</p> <p>Replace with higher rated hoses.</p>

# TROUBLE-SHOOTING GUIDE (continued)

PROBLEM	POSSIBLE CAUSE	POSSIBLE REMEDY
<b>Hydraulic hose failure. (CONT.)</b>	4. Hose is being pinched by movement of loader mount or loader linkage.	Reroute hose and refasten.
<b>Hydraulic oil overheats.</b>	1. Hydraulic oil level in tractor may be low. 2. Hydraulic oil or oil filter in tractor may be dirty. 3. Hydraulic oil reservoir of tractor may be small.	Check and add oil.  Change oil and filter according to power unit manufacturer's recommendations.  Allow time for oil to cool down.
<b>Bale Handler is off to one side of tractor and loader.</b>	1. Lift brackets on frame not set correctly.	Loosen brackets and measure from center of frame to position correctly.
<b>Bale shape is greatly distorted when clamped.</b>	1. Bale too soft.	Re-adjust baler to have firmer bale.
<b>Hooks pull out of bale.</b>	1. Not enough hooks in bale.	Add more hooks.
<b>Tilt cylinders won't pull Bale Handler back after positioning horizontally.</b>	1. Loader tilt cylinders are too close to loader arm pins in lift channels. 2. Loader too small for weight of bale being handled. 3. Hydraulic system not operating at correct pressure.	Move further apart.  Use larger tractor with larger size loader.  Check pressure and adjust or repair.
<b>Excessive rear tractor tire slippage.</b>	1. Tractor too small. 2. Insufficient traction.	Use larger, heavier tractor.  Add rear tire weights or add ballast in tire. Use tractor with FWDA.


# RBH-4000 BALE HANDLER PARTS



## RBH-4000 BALE HANDLER PARTS LIST

Ref. No.	Part No.	Description	No. Req'd.
1	831461	Main Frame Weldment	1
2	831490	Shaft Bearing Repair Kit (for one side of unit) Includes (1) Top Cap, (4) 1 1/2" Square Shaft Bearings, (2) 3/16" Poly Spacers, & (3) 3/8" Square Stops	2
3	831479	Tine Shaft	2
4	830863	Top Cap (Welded)	2
5	831480	Curved Hay Hook	10
6	831481	Crank Arm Weldment	2
7	2503294	U-Bolt 1/2"-13NC (for 1 1/2" Sq. Tube)	14
8	2500040	Nut 1/2"-13NC Whiz Flange Hex	28
9	831276	Forged Tine (23.6")	6
10	831279	Nut, Special Tine (M22)	6
11	831277	Forged Tine (31.9")	5
12	831274	Nut, Special Tine (M28)	5
13	830317	Lift Bracket	2
14	830309	Lift Pin Ø1" x 8"	4
15	590034	Linchpin 1/4" (AK-61)	8
16	830214	U-Bolt 5/8"-11NC x 3" ID x 4 1/2" Lg.	4
17	2502007	Washer 5/8" Springlock	8
18	2500013	Nut 5/8"-11NC Full Hex	8
19	2504071	Hydraulic Cylinder 2 1/2 x 8	2
20	2504081	Hydraulic Hose 3/8" x 18"	4
21	2505553	Hydraulic Tee 1/2" NPT	2
22	2504165	90° Elbow 3/8" NPT	4
23	831485	Tee Clamp Plate	1
24	2500042	Nut 3/8"-16NC Hex Nylock	1
25	101026	Safety Sign - Warning (Read Owner's Manual)	2
26	101027	Safety Sign - Warning (Stand Clear)	2
27	101122	Safety Sign - Warning (Hi-Pressure Fluid)	1

# RBH-4000 BALE HANDLER PARTS LIST



Ref. No.	Part No.	Description	No. Req'd.
1	2504071	Hydraulic Cylinder 2 1/2 x 8	2
2	2504081	Hydraulic Hose 3/8" x 18"	4
3	2504165	90 deg Elbow 3/8" NPT	4
4	831485	Tee Clamp Plate	1
5	2505553	Hydraulic Tee 1/2" NPT	2

# **⚠ SAFETY PRECAUTIONS ⚠**

**MOST ACCIDENTS OCCUR BECAUSE OF NEGLIGENCE OR CARELESSNESS.  
AVOID NEEDLESS ACCIDENTS BY FOLLOWING ALL OF THE SAFETY PRECAUTIONS LISTED BELOW.**

- Machinery should be operated only by those who are responsible and are authorized to do so.
- Stop the engine, lower all equipment, lock the brakes, and remove the ignition key before dismounting from the tractor.
- Never stand between tractor and implement while tractor is being backed to hitch.
- Loose fitting clothing should not be worn, to avoid catching on various parts.
- Detach implement in area where children normally do not play.
- When performing adjustments or maintenance on an implement, first lower it to the ground or block it securely at a workable height.
- Only a qualified operator should be permitted on tractor when in operation; no riders allowed.
- Make certain everyone is in the clear before starting tractor or raising or lowering equipment.
- Operate the tractor and implement only while seated in the driver's seat.
- Reduce speed when transporting mounted implements to avoid bouncing and momentary loss of steering control.
- A heavy load can cause instability of the tractor. Use extreme care during road travel. Slow down on turns and watch out for bumps. Tractor may need front counterweights to counter-balance the weight of the implement.
- Reduce speed on hillsides or curves so there is no danger of tipping.
- Avoid driving too close to the edge of ditches or creeks.
- Do not transport implement on public roads without reflectors and slow moving vehicle emblem in daylight and with approved warning lights at night and other periods of poor visibility.
- Due to the width of some implements, use extra caution on highways, farm roads, and when approaching gates.
- Always be sure the implement is in the proper position for transport.
- Keep alert and watch the front as well as the rear when working with the implement.

**OWNER'S/  
OPERATOR'S  
MANUAL**

**MODEL NO.  
RBH-4000  
and  
Telehandler  
Models**

JULY 2004

## **RECTANGULAR BALE HANDLER**

**WHEN ORDERING REPAIR PARTS,  
ALWAYS GIVE THE FOLLOWING INFORMATION:**

1. PART NUMBER
2. PART DESCRIPTION
3. MODEL NUMBER
4. NAME OF ITEM

**MAKE EVERY DAY  
A HOLIDAY  
FROM ACCIDENTS!**

**WORKSAVER, INC.**

P.O. BOX 100 LITCHFIELD, IL 62056-0100 (217) 324-5973  
WEB: <http://www.worksaver.com> E-MAIL: [sales@worksaver.com](mailto:sales@worksaver.com)